

NBS SPECIFICATION CLAUSE FOR HYGIENIK 35mm PARTITION – 01.08.18

K30 Panel Partitions

TYPES OF PARTITION

112 RE-LOCATABLE WALL SYSTEM: 35mm PARTITION

- Partition type: Temporary or Permanent
- Partition System:
 - Manufacturer: **Hygienik Systems Limited**
10-14 Ward Street, Bradford, West Yorkshire, BD7 3PR
Telephone: 01274 578 051 Email: matt@hygienee.com
www.hygienee.com
 - Product reference: **35mm Partition**
 - Panel Type: Extruded PVC Panel Partition
 - Panel Thickness: 35mm
 - Panel Widths: 500mm
 - Panel Material Source: Recycled PVC
 - Colour: White
 - Fixings: Consult with Manufacturer, identifying Partition Height
- Partition height: As Architects / Designers Drawings (Maximum 6m).
- Partition abutments:
 - Head: Duraspan Head Channel.
Deflection allowance: To Structural Engineer's Recommendation.
 - Floor: Duraspan Base Track Channel.
 - Wall/ Vertical structure: Duraspan Wall Channel.
- Partition joints:
 - Vertical: Interlocking Panels
 - Horizontal: Duraspan H-Section
 - 90 Degree Corners: Right Angled Corner Profile
 - Non-90 Degree Corners: 50mm Flexi Angle
- Accessories: Flexi Angle at Window Reveals / Openings.

INSTALLATION

410 WORKMANSHIP GENERALLY

- Setting out: Plumb, true to line and level, and free from bowing, undulations and other planar distortions.
- Joints: Align accurately with no lipping.
- Stability: Fix securely, with additional supports where necessary at perimeters.
- Moisture and thermal movement of framing/ panels: Make adequate allowance.

425 INSTALLING RE-LOCATABLE PARTITIONS

- Site dimensions: Check before installation. Give notice of discrepancies.
- Perimeter abutments: Accommodate deviations whilst maintaining partition system performance. Form make up/ closer pieces accurately around projections and features.
- Customisation: Do not cut or otherwise alter framing/ panels on site, except where shown on drawings.
- Intermediate joints in exposed frame members and trims: Keep to a minimum.